ATp (4769) Wiring Diagram/Installation Instructions

BATTERY MUST BE CHARGED FOR 24HRS BEFORE INITIAL USE

DO NOT INSTAL DEVICE IN ENGINE COMPARMENT

What comes in the box?

1. Your tracking device (see models below)



2. The power cable for wiring your tracking device into vehicle







For more detailed installation information, including pictures, go to: www.rhinofleettracking.com/install



View your account at: http://www.rhinofleettracking.com

ATp (4769) Wiring Diagram/Installation Instructions

BATTERY MUST BE CHARGED FOR 24HRS BEFORE INITIAL USE

DO NOT INSTAL DEVICE IN ENGINE COMPARMENT

Two ends of ATp power cable




IMPORTANT!!!
THE BLUE, YELLOW, GREEN, BROWN
AND ORANGE WIRES ARE NOT USED FOI
YOUR INSTALL SO DISREGARD THESE
WIRES.

TAPE THEM OFF, CUT THEM OR LEAVE THEM HANGING IT'S UP TO YOU.

Black wire goes to ground source (Find a ground wire, ground to chassis or to negative battery terminal)

White wire goes to ignition source (IMPORTANT!! See NOTE below)



Once wired, push wake-up button and hold until you see the LEDs light up then release.





Plug in here



ATp tracking device

NOTE: There are a variety of wires inside any given vehicle that may simulate an ignition wire. Examples being remote wires for car stereos or accessory wires for various accessories. THESE ARE NOT IGNITION WIRES. If you do not wire to a true ignition wire, the device will not report properly. It will report false ignitions which will also subsequently make other things like trips and stops report incorrectly as well.

*****BATTERY MUST BE CHARGED FOR 24HRS BEFORE INITIAL USE******

IMPORTANT!!! PLEASE READ IF VEHICLE OR ASSET DOES NOT HAVE AN IGNITION WIRE
IF YOU ARE INSTALLING THIS DEVICE IN A VEHICLE OR ASSET THAT HAS AN IGNITION WIRE, WIRE AS SHOWN ABOVE.

IF YOUR VEHICLE OR ASSET DOES NOT HAVE AN IGNITION WIRE, FOR EXAMPLE ON A TRAILER, YOU CAN TWIST THE RED AND WHITE WIRES TOGETHER AND WIRE THEM TO A 12V CONSTANT SOURCE WHICH ON TRAILERS IS USUALLY FOUND IN ABS CONNECTOR. THESE COME IN VARIOUS PINOUTS SO CONTACT YOUR MANUFACTURER FOR WIRING DIAGRAM FOR YOUR TRAILERS ABS CONNECTOR.





For more detailed installation information, including pictures, go to: https://www.rhinofleettracking.com/install



View your account at: https://www.rhinofleettracking.com